

Small void on either side of truck after installing our 1979 + newer tub onto a STEEL COWL only

After your original tub has been removed and our replacement tub has been bolted into position you will be left with a small void on either side of your truck.

These cover plates will need to be secured to the exterior of your truck to conceal and at the same time strengthen this area.

Once these cover plates have been bolted into position we recommend running a small bead of seam sealer or Sikaflex around the outside perimeter to keep moisture out.

Another option is instead of using these cover plates is to weld a new piece of steel sheet metal to the existing front cowl. This sheet metal should have a 90 degree bend that ties back onto the door post. This will then give you a mounting surface to bolt the aluminum body to your existing cowl.

