

#4006 1979 + Newer Body Bolt Pkg. Manifest

32-3/8" X 1" s/s (stainless steel) bolts; 32 steel nylocs; 60-3/8" flat washers; 4- oversize 3/8" flat washers:

- 2- to mount replacement body to existing body (door frame)
- 4- to bolt replacement floor pan to existing floor pan
- 2- to mount front of gas tank straps to driver's side
- 2- to mount front of gas tank straps to passenger's side
- 4- to mount front of seat brackets to body: passenger and driver's sides (4, oversize, 3/8" washers).
- 8- to mount spare tire carrier
- 8- to mount back jump seats
- 2- to mount seat belt straps to body

16-3/8" x 1 1/4" s/s bolts; 16 steel nylocs; 32-3/8" s/s flat washers:

- 16- to bolt roll bar down.

2-7/16" x 5" plated bolts; 2-7/16" steel nylocs; 4-7/16" s/s flat washers:

These bolts are to mount the very back of the replacement body to frame. Use existing pilot holes as a guide.

2-7/16" x 4 1/2" plated bolts; 2-7/16" steel nylocs; 4-7/16" s/s flat washers:

To mount back portion of gas tank straps.

2-7/16" x 3" plated bolts; 2-7/16" steel nylocs; 4-7/16" s/s flat washers:

Once front and back section of body is secure, lie on your back and drill through existing holes in frame into the aluminum replacement body.

6-10/24" x 3/4" oval head machine screws; 6-10/24, s/s nylocs; 6 s/s flat washers:

- 6- to mount front cover plates to existing body (6 nylocs, 6 flat washers)

34-#8 x 3/4" s/s pan head teckscrews (Phillips); 4-10/24 s/s flat washers:

- 10- to mount transmission cover
- 8- to mount four rubber mounts (on bottom side of tub)
- 4- to mount heater (4 flat washers)
- 4- to mount gas door and catch
- 4- to mount cover over fill hose of fuel tank, located under body by passenger rear wheel.
- 4- to mount side marker lights.

28-5/16" x 1" s/s bolts; 28 steel nylocs; 42-5/16" s/s flat washers:

- 14- to mount hard top (no flat washers bottom side).
- 14- to mount running boards

4-5/16" x 1 1/4" s/s bolts; 4- steel nylocs; 8-5/16" s/s flat washers:

- 4- to mount emergency brake handle in place

15-1/4" x 3/4" s/s bolts; 15 steel nylocs; 30-1/4" s/s flat washers:

- 4- to mount jack handle.
- 8- to mount hinges on back doors
- 3- to mount jack holder.

4-5/16" x 3" s/s bolts; 4 steel nylocs; 8-5/16" s/s flat washers:

- 4- to mount tire carrier bracket support and catch.