Fitting your Hood Side Panels to your cowl

When fitting your hood side panels/ fenders and hood there are a few things to consider:

Firstly your hood side panels must be shimmed at the back. We suggest some form of rubber bolted from cowl into hood side panels, this is a suggestion that may or may not work for your application. See attached pictures.